

Duct Insulation 101: Fundamentals and Basics

By Darrell Peil



As buildings grow more complex and energy standards tighten, duct insulation plays a larger role in system performance.

Without duct insulation, energy losses are 85%–90%* higher for the duct system, condensation can drip, temperature control is more difficult, and microbial growth becomes routine—raising ownership and management costs.

Duct insulation is an easy, cost-effective energy control measure that is often overlooked. With many new entrants to mechanical systems design, a basic introduction to duct insulation, its uses, and impacts is timely.

What is Duct Insulation?



Duct insulation is a thermal and acoustic energy control medium supplied in sheets of varying thicknesses, widths and lengths. Installers fit sheets to square, rectangular, or round ducts at fabrication, pre-installation, or in place. Most is applied externally; special duct liner insulation is designed and tested for prolonged airstream contact on internal duct surfaces.

Duct insulation functions passively, with no ongoing energy input, offering short-term payback and long-term performance. Guidance appears in ASHRAE's Handbook of Fundamentals (Ch. 8 – Sound and Vibration; Ch. 23 – Insulation for Mechanical Systems) and Handbook – HVAC Applications (Ch. 49 – Noise and Vibration

Control), maintained by ASHRAE TC 1.8 (Mechanical Systems Insulation) and TC 2.6 (Sound and Vibration).

Ducts insulated in practice are made of steel, copper, aluminum, stainless steel, fiber-reinforced plastic (FRP), or flexible polymer materials. They range from high-pressure, high-velocity industrial systems to low-pressure, low velocity residential systems. Reported extremes include a 26-foot diameter ventilation shaft and specialized 2-inch diameter high-pressure ducts.

Why Use Duct Insulation?

There are many reasons for using duct insulation. The primary reasons are:

- **Slow heat loss or gain.** Reducing heat transfer conserves energy and helps maintain process temperature ranges.
- **Economical facility operations.** Lower energy use for heating/cooling air reduces utility costs.
- **Condensation control on cooled/chilled air ducts.** Proper thickness keeps exterior surfaces above dewpoint; an effective vapor retarder is required.
- **Acoustical control.** Some materials also limit sound transmission from high-velocity air or duct movement, improving occupied-space acoustics.
- **Fire safety.** Most duct insulation has low flame spread and smoke generation to limit fire/smoke transport through duct pathways and plenum spaces. High-temperature insulation on commercial kitchen exhaust ducts helps contain grease fires.

The secondary reasons are:

- **Personnel protection/safety.** Adequate insulation lowers surface temperatures on hot ducts to mitigate burn hazards.
- **Carbon sequestration/decarbonization.** By reducing operating energy, insulation directly lowers operational carbon emissions (2025 Handbook of Fundamentals).

Types of Materials Used to Produce Duct Insulation



Many types of material are used to make duct insulation. Common materials include:

- Mineral fiber (fiberglass/glass fiber and rock/slag fiber)
- Other mineral-based products (cellular foamed glass, calcium silicate, alkaline earth silicate)
- Synthetic rubber expanded foams (mostly closed-cell; some open-cell)
- Other polymer foams (expanded/extruded polystyrene, polyisocyanurate, polyolefin, phenolic, melamine)

Each material has characteristics suited to specific conditions; proper application understanding is essential for selection.

Basic Forms of Duct Insulation



Flexible Wrap on Rectangular Duct

Flexible Wrap on Oval

Rigid Board on Rectangular Duct

Most products are factory-formed sheets (rigid or flexible) in standard thicknesses, widths and lengths. Available sheet sizes determine how much piecing is needed to create a complete insulation envelope. Duct insulation materials may be supplied with or without factory-applied vapor retarder facings depending on the needs of the project.

Key Performance Properties

Each material type has an ASTM specification (in North America) and standardized tests to validate key properties. Key properties include:

- Thermal conductivity: Heat flow through material at a given mean temperature (ASTM C177 or C518).

- Continuous service/usage temperature range: Upper limit via ASTM C411; no standardized lower limit (producer-determined). Intermittent “spike” temperatures are not standardized; use continuous service temperature.
- Water and water vapor transport: Water vapor transmission (ASTM E96); water vapor sorption of unfaced mineral fiber insulation (ASTM C1104); liquid retention by immersion (ASTM C1763).
- Sound control: Sound absorption (ASTM C423) and sound transmission reduction through duct systems (ASTM C477).
- Fire response: Flame spread/smoke developed (ASTM E84; typical requirements 25/50); non-combustibility screening (ASTM 136); specialized tests for fire-containment duct systems. UL 181 and NFPA 90A/90B require 25/50 indices. Note: E84 yields numerical indices, not pass/fail.
- Dimensional characteristics: Thickness accuracy is critical to performance (ASTM C167 or C303 for factory-formed products). Field-applied flexible wraps may not achieve design thickness and should be verified in the field.

This is not an exhaustive list but covers basic properties for performance and safety.

Sizing

Standard thicknesses range from ½ inches to more than 4 inches. Greater thicknesses may be built up in multiple layers. For extreme hot or cold systems, multi-layer construction may be required to avoid thermal leaks. Thicknesses typically change in ½ inch increments.

Basic Installation Practices – Warm

Warm or hot installations apply to systems operating above ambient temperature. For these systems:

- Focus on minimizing heat loss and achieving a clean finish.
- Vapor retarder sealing is less critical than for cold systems.
- Duct supports are commonly encased; best practice uses high-compressive-strength insulation inserts between duct and support to reduce energy losses and vibration transmission.

Basic Installation Practices – Cold

Cold installations apply to systems operating below ambient temperature. For these systems:

- Focus on limiting heat gain, condensation control, and finish quality.
 - Vapor retarder integrity is critical; incorporate vapor stops per current industry guidance.
 - Factory-applied vapor retarder facings must be fully sealed; avoid stapling that penetrates the retarder.
- Ensure smooth transitions and complete vapor retarder continuity at all joints and seams.



Smooth transitions, completed vapor retarder

- Fittings (e.g. elbows, tees) must receive full design thickness via proper field fabrication.
- Do not encase duct supports within the insulation envelope. This practice reduces the formation of condensation from cold duct supports and avoids openings in the system that allow water vapor into the insulation system, destroying the installation.



Duct supports outside of insulation envelope

Key Problem Spots

Most duct insulation systems perform well, but common issues still occur. These include over-compressing blanket insulations (reducing R-value), overstated product claims, and uncertainty over correct duct liner installation.

Completing vapor retarder systems on cold work (including sealing factory facings and both longitudinal and circumferential seams) is time-intensive but essential. Maintaining full-thickness insulation at fittings and properly detailing supports/hangers are frequent concerns.

For hot systems, gaps at fittings cause hot spots, finish deformation and/or discoloration, and increased heat loss. Design discussions commonly center on

thickness and product selections, conflicting specifications, and space allowances for duct insulation required by Standard 90.1.

Recent Developments

It is often said that there is nothing new in the duct insulation market. This is not the case. This is still an active market segment. Just some of the developments that have been brought to market in recent years:

- New vapor retarder facings with polymer film surfacing
- Plant-based binders for mineral fiber
- Increased recycled content in fiberglass via updated formulations and equipment
- New vapor retarder and finishing materials



Flexible laminated pressure sensitive field-applied vapor barrier applied over board insulation

-
- Standards addressing IAQ/IEQ impacts
- Alternative materials for duct insulation
- Expanded size offerings

Resources

Many industry publications and organizations provide information on duct insulation and installation.

Trade Associations/Societies:

- American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE) – <https://www.ashrae.org/>
- ASTM International – <https://www.astm.org/>
- National Insulation Association (NIA) – <https://insulation.org/resources/>
- North American Insulation Manufacturers Association (NAIMA) – <https://insulationinstitute.org/tools-resources/>

Publications and tools:

- ASHRAE Handbook of Fundamentals – <https://www.ashrae.org/technical-resources/ashrae-handbook/ashrae-handbook-online>
- North American Commercial and Industrial Insulation Standards Manual (Midwest Insulation Contractors Association) – https://micainsulation.org/aws/DBX/pt/sp/MICA_standards
- A Guide to Insulated HVAC Systems (North American Insulation Manufacturers Association) – <https://insulationinstitute.org/wp-content/uploads/2016/01/AH121.pdf>
- Tech Notes: Duct Insulation – Do it Right the First Time (North American Insulation Manufacturers Association) – <https://insulationinstitute.org/wp-content/uploads/2016/01/AH147.pdf>
- 3E Plus Thickness Calculator – <https://www.3eplus.org/>

This is an introduction to duct insulation system design and installation. Many books cover the topic in depth, and union insulation mechanics train for years in best practices. The subject is broad and its impacts significant; these fundamentals and resources will help guide further study.

As codes evolve and systems become more demanding, insulation remains one of the most practical ways to improve efficiency and reliability. The materials, standards, and installation methods continue to advance, giving designers and contractors more options than ever.

*NAIMA 3E Plus Insulation Calculator